





Symphone N5000
mobile computer
user guide



Mobile phone illustrations and instructions



Power button

Press and hold this button to power on/off the phone.

Volume button

Adjust the volume. When pressing this button when there is an incoming call, the ringing will become mute.


Power button + volume subtraction button

After lighting the screen, this action can take a screenshot.

Scanning button

Click to start scanning in the application.

Mobile phone illustrations and instructions




Notice:


Please do not point laser at eyes. Long exposure can cause unrecoverable damage the eyes.

Installation and preparation

Please insert the SIM card and battery before using the phone. Make sure the phone is turned off before the battery or SIM card is removed from the phone.




1. Open the back cover



2. Remove the battery

Installation and preparation



3. Insert SIM card

Please do not use any non-compatible card or non-standard SIM card, otherwise it will damage your phone.

This phone uses a Micro SIM card.



Common question

Q: How to you extend the standby time of the mobile phone?

Answer:

1. If you do not need to use the mobile network to browse the internet or upload and download data, you can turn off the network data connection. Go to settings > wireless and network > more... > mobile network.

2. If you do not need to use the WLAN or Bluetooth, you can turn off the WLAN or Bluetooth. Change this by going to settings > wireless and network > WLAN or Bluetooth.

3. If you do not need to use GPS, you can turn off the GPS. Go to settings > information location access > GPS satellite.

4. Screen brightness and duration of sleep will affect the standby time of the phone. You can adjust these two settings by going to settings > display.

5. Exit and shut down the applications that are not in use.

6. Reduce the volume.

Q: How to free up phone memory?

Answer:

1. Move the files and e-mail attachments to the Micro SD card.

2. Remove all cache pages and browsing history information from the browser.

3. Uninstall the applications which are no longer necessary.

Using tips

Important tips

In order to avoid unnecessary harm, please note the following information when using the phone.

Please do not turn on the phone where wireless devices are forbidden to use, including aircrafts, medical facilities and medical equipment indicating not to use mobile phones.

Please do not turn on the phone where it may cause interference or danger, such as around petrol stations, fuel or chemicals, blasting areas, etc.

Please use the original accessories and battery, do not use incompatible products.

Keep the phone dry.

- Please find qualified maintenance staff to repair mobile phones.

Please consult the connection method in the instructions when connecting to other devices. Do not connect to unsuitable devices.

Battery charging

The battery icon in the upper right corner of the screen shows electricity quantity or charging status, you can also choose to show the percentage of electricity quantity.
(Trick in the select box in setting > battery > electricity quantity percentage)

Please charge by using the attached charger connected to a power outlet or connecting to a computer with a USB cable.

Using tips

Connect the phone to the computer

Connect to the computer with a USB cable, open the data storage through the pop-up window or drop-down notification bar. While using the data storage, a part of the program cannot be used, such as file management, etc.

Open the back cover

Gently pull the opening in the lower left corner of the N5000 outwards to remove the back cover.

Insert or remove the battery

Align the battery metal contact entrance with the body battery contactor. Press down to insert the battery. To remove the battery, pull the battery out of the recess at the bottom or the battery compartment.

Mobile phone configuration

Processor	Dual core 1.2GHZ
Bands support	WCDMA: Band I (2100) Band VIII (900), GSM: 900/1800/1900
Style	Full touch screen, stylish look
LCD	5.0qHD
System memory	4GB (ROM) + 1GB (RAM)
Size	146.7*73*9.3(mm) (length*width*thickness)
Weight (including battery)	155g
Battery capacity	2500mAh
Wireless transmission mode	Bluetooth / WiFi
User memory mode	T-Flash card slot, maximum support 32GB capacity card
Scanning head	Scanning head professional 1D / 2D scanning head

Mobile phone configuration

Camera	Rear camera: 5 million pixel autofocus camera + double LED flash Front camera + double LED flash
USB type	USB 2.0
Touch screen	Capacitive touch screen
Fast charging	3 hours
Host protection function	After free drops at a height of 80cm for 6 times (one time per side), the device is not damaged.
The CTA certification	Network access license of telecommunications device, Radio transmitting device, Model approval certificate.

Safety tips

Declaration of toxic and hazardous substances in electronic information products.

Component	Harmful Substance					
	Lead (Pb)	Mercury (Hg)	Polybrominated Biphenyls (PBB)	Cadmium (CD)	Six valence Chromium (CR (VI))	Polybrominated Diphenyl Ethers (PBDE)
Host	×	○	○	○	○	○
Charge	×	○	○	○	○	○
Battery	×	○	○	○	○	○
Cable	○	○	○	○	○	○

This form is compiled in accordance with the SJ/T 11364.

○ : It represents that the content of this hazardous substance contained in all homogeneous materials for this component is all under the limit requirement in GB/T 26572

×

X : It represents that the content of this hazardous substance contained in all homogeneous materials or at least one component is above the limitation in GB/T 26572, and there is no mature alternatives in the industry, meeting the environmental protection requirements of EU ROHs instructions.



The number in this logo represents that the products have a 20 years environmentally friendly use period under normal conditions. Some other components may also have an environmentally friendly use period logo, their environmentally friendly use period depends on the number in the logo. Because of different models, the product may not include all of the above parts, except for the host, please refer to our actual sales product configurations.



Newland

SCANNING MADE SIMPLE

Newland EMEA HQ

+31 (0) 345 87 00 33
info@newland-id.com
newland-id.com

D-A-C-H

+49 (6) 182 82916-16
info@newland-id.de

United Kingdom

+44 (0) 1442 212020
sales@newland-id.co.uk

France

+39 (0) 345 8804096
france@newland-id.com

Russia

8 (800) 100 46 22
russia@newland-id.com

Benelux

+31 (0) 345 87 00 33
benelux@newland-id.com

South Africa

Gauteng: +27 (0) 11 553 8010
Cape Town: +27 (0) 21 9140819
info@newland-id.co.za

Ibérica

+34 (0) 93 303 74 66
info@newland-id.es

Middle East

+39 (0) 345 8804096
middleeast@newland-id.com

Italy

+39 (0) 342 0562227
italy@newland-id.com

Turkey

+90 (0) 544 538 40 49
turkey@newland-id.com

Nordic & Baltic

+46 (0) 70 88 47 767
nordic@newland-id.com

Iran

+90 (0) 544 538 40 49
iran@newland-id.com